

# **User Manual**

## VLC Modular Chiller

Rev. 03 | September 2023




| <b>Review History</b>       |             |                      |                 |
|-----------------------------|-------------|----------------------|-----------------|
| <b>First Edition</b>        | <b>Date</b> | <b>Elaborated by</b> | <b>Approval</b> |
| New Version                 | 2/10/2023   | CPJ                  | GOG             |
| <b>Revision Description</b> | <b>Date</b> | <b>Change</b>        | <b>Approval</b> |
| Options review              | 17/04/2023  | GAAC                 | WRR             |
| Data table update           | 26/04/2023  | CPJ                  | GOG             |
| Change control to 220V      | 06/09/2023  | FAF                  | WRR             |
|                             |             |                      |                 |
|                             |             |                      |                 |

## ABOUT THE MANUAL

The purpose of this manual is to provide the necessary information for the installation, operation and maintenance, which are enough to ensure the operation of the equipment under the conditions for which it was designed.

Considering that technological advancements will occur, Mecalor reserves the right to change this manual and the design of the equipment without prior warning.

Words like DANGER, ATTENTION and INFORMATION are used in the course of the manual to show warning situations as shown below:

|   |                    |  |
|---|--------------------|--|
|  | <b>DANGER</b>      | Warns about immediate danger that may cause serious injuries or death.                   |
|  | <b>ATTENTION</b>   | Warns about unsafe practices, which if not avoided, may cause personal damages or death. |
|  | <b>INFORMATION</b> | Relevant information about the equipment or recommendation about good working practices. |

## MANUFACTURER

Klimatix a division of Mecalor Soluções em Engenharia Térmica S.A.

CNPJ [Corporate Taxpayers Registration]: 49.031.776/0001-68


Rua da Bandeira, 219, Parque Novo Mundo, São Paulo - Brasil - ZIP code: 02181-170


## CONTACT

Telephone: +55 (11) 2188-3470

Website: [www.klimatix.com](http://www.klimatix.com)

e-mail: [atecnica@mecalor.com.br](mailto:atecnica@mecalor.com.br)

|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | <b>Keep this manual in a place that is accessible to the user to consult in case of doubt.</b><br>This manual cannot be reproduced whole or in part without the prior authorization from Mecalor. |
|---|--------------------|---|

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | <b>Do not perform any procedure on the equipment in case of doubt after reading this manual.</b><br>This manual should guide the operator of the equipment, providing relevant information. Contact the technical support of Mecalor in case of doubt. |
|---|--------------------|--|

**TABLE OF CONTENTS**

- 1.1. Equipment Description ..... 3
- 1.2. Application scope ..... 9
- 1.3. Optional items installed at the factory or on the field ..... 10
- 2. TECHNICAL FEATURES ..... 10**
  - 2.1. Nomenclature ..... 10
  - 2.2. Technical Information ..... 11
  - 2.3. Identification plate attached to the VLC ..... 14
  - 2.4. Operating limits ..... 14
  - 2.5. Dimensions ..... 15
  - 2.6. Electrical Data ..... 17
- 3. RECEIVING ..... 18**
  - 3.1. Packaging ..... 18
  - 3.2. Unloading, Moving and Storage ..... 19
- 4. INSTALLATION ..... 20**
  - 4.1. Installation site ..... 20
    - 4.1.1. Air exhaust duct ..... 221
  - 4.2. Electrical installation ..... 233
  - 4.3. Hydraulic Installation ..... 30
    - 4.3.1. Material ..... 30
    - 4.3.2. Interconnection Points ..... 30
    - 4.3.3. Interconnection in parallel ..... 32
      - 4.3.3.1. Interconnection with a single pump ..... 32
        - 4.3.3.1.1. Interconnection with single pump - Variable speed pump ..... 33
      - 4.3.3.2. Interconnection with individual pumps ..... 33
    - 4.3.4. Need to add anti-freezing agent ..... 34
    - 4.3.5. Pipe Cleaning ..... 35
  - 4.4. Optional Installation ..... 35
    - 4.4.1. Bacnet Communication ..... 35
    - 4.4.2. Parallel interconnect kit ..... 35
    - 4.4.3. Air filter ..... 36
    - 4.4.4. Condenser with e-coating ..... 36

|            |   |            |
|------------|---|------------|
| 4.4.5.     | Service HMI.....                          | 36         |
| 4.4.6.     | Remote Monitoring .....                   | 367        |
| 4.5.       | Start-up check-list.....                  | 377        |
| <b>5.</b>  | <b>OPERATION .....</b>                    | <b>388</b> |
| 5.1.       | Start-up.....                             | 399        |
| 5.2.       | HMI – Human Machine Interface .....       | 40         |
| <b>6.</b>  | <b>MAINTENANCE .....</b>                  | <b>42</b>  |
| 6.1.       | Corrective Maintenance .....              | 422        |
| 6.2.       | Fault indication .....                    | 422        |
| 6.3.       | Preventive Maintenance .....              | 499        |
| <b>7.</b>  | <b>TECHNICAL SERVICES .....</b>           | <b>544</b> |
| 7.1.       | Start-up.....                             | 544        |
| 7.2.       | Preventive Maintenance Agreements.....    | 544        |
| 7.3.       | Retrofitting (Reform of Equipments).....  | 555        |
| 7.4.       | Training.....                             | 555        |
| <b>8.</b>  | <b>DISPOSAL AND THE ENVIRONMENT .....</b> | <b>555</b> |
| <b>9.</b>  | <b>WARRANTY TERM.....</b>                 | <b>566</b> |
| <b>10.</b> | <b>ATTACHMENTS .....</b>                  | <b>577</b> |

## General Description of the Product



### 1.1. Equipment Description

This equipment incorporates, in a single cabinet, all the refrigeration components required for liquid refrigeration, controlling the temperature with precision and adjusting its capacity according to the variations in the thermal load of the process, according to a predefined (*setpoint*) temperature.

Assembled in a compact carbon steel structure, powder painted with 70-micron thickness in olive green (RAL 6003), the VLC was designed to meet different demands of thermal load in applications of environment acclimatization or cooling of various processes, allowing the combination of up to 14 units in parallel, with individual control, therefore without the dependence on a single equipment, thus expanding the refrigeration capacity and modulation, with a system composed of compact equipment and reduced floor area.

The design was created to optimize energy efficiency, ensuring stable and adjustable temperature control to the variation of thermal load in the climatization of the environment or system served. Reference components in quality and technology were considered, ensuring not only the conventional functionalities but also a stable and robust operation. The equipment is divided into three main systems, according to the application: refrigeration circuit (refrigeration), hydraulic circuit, and control.




|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | Design developed and built according to standards NR-10 (electrical safety) and NR-12 (operator protection).  |
|  | <b>ATTENTION</b>   | The adulteration of original components installed in the VLC is prohibited. This practice may put at risk the safety of the operator, the good functioning of the equipment and the loss of warranty. |

### 1.1.1. Refrigeration circuit


The refrigeration system of the VLC consists of a hermetic scroll compressor (1), available in versions with fixed tandem compressor or with inverter compressor, which is responsible for continuously sending the refrigerant in the form of hot gas to the condenser (2). In this condenser the refrigerant changes from overheated steam to sub-cooled liquid, and through this change of state, the condensing air receives the enthalpy (raising its temperature) of the refrigerant, passing through the condenser with the aid of a fan (3).

The refrigerant in the sub-cooled liquid condition passes through a filter drier (4), which is responsible for eliminating impurities and moisture present in the system. In addition to a liquid display (5), which is responsible for visually indicating the fluid situation inside the piping. When passing through the expansion valve (6) the refrigerant suffers a pressure drop, entering in the form of saturated liquid in the evaporator (7). Inside the evaporator the refrigerant fluid receives heat from the process fluid, going from the saturated liquid state to overheated steam, condition in which it can enter the compressor and restart the cooling cycle. As shown in the diagram below, the VLC uses a plate evaporator.


- Version with tandem compressors (VLC-A-15/18-F):



- Version with inverter compressor (VLC-15/18-I):



| Item | Description                               |
|------|---|
| 1    | Hermetic Scroll Compressor                |
| 2    | Microchannel Condenser (Air condensation) |
| 3    | Fan                                       |
| 4    | Filter Drier                              |
| 5    | Liquid Display                            |
| 6    | Electronic Expansion Valve                |
| 7    | Evaporator                                |

|   |               |   |
|---|---------------|---|
|  | <b>DANGER</b> | <p><b>The compressors are equipments that operate with differential pressure between suction and discharge.</b></p> <p>In suction, according to the condition of use, the pressure and temperature are low, which may cause burns.</p> <p>In discharge, according to the condition of use, the pressure and temperature are high, which may cause burns.</p> <p>The interior of the equipment should only be accessed by qualified personnel and Personal Protective Equipment (PPE).</p> |
|---|---------------|---|






### INFORMATION

A high pressure switch monitors the discharge pressure of the compressor, in case the pressure reaches the maximum safety value, it switches off the equipment.

#### 1.1.2. Hydraulic circuit

The equipment is supplied ready for connection to the hydraulic circuit of the system, through Victaulic coupling type connections.

The return water from the process enters the equipment by initially passing through the Y filter for retaining solid particles (8), followed by the flow sensor (9), a component responsible for monitoring the water flow, ensuring that the water flow remains constant and within the operating limits so that there is no risk of freezing inside the evaporator. Subsequently, the water circulates through the evaporator (10) where it loses heat to the refrigerant inside the evaporator, proceeding to the outlet pipe, where it is directed to cool the process. This configuration is identical in all available versions of the VLC.



| Item | Description  |
|------|--------------|
| 8    | Water filter |
| 9    | Flow sensor  |
| 10   | Evaporator   |

#### 1.1.3. Control

All the electrical control and command components are installed inside the electrical panel (11), IP 54 protection, in the front part of the equipment.

The control is performed by means of a semi-graphic interface (11) installed in the front part of the equipment, and a rotating handle (12) for activating the general switch, with the purpose of powering the equipment. The components for sectioning, control, and interconnection of units are located inside the electrical panel.




| Item | Description            |
|------|------------------------|
| 11   | Semi-graphic interface |
| 12   | Key Switch             |

#### 1.1.3.1. Electrical panel components - Version with fixed tandem compressors (VLC-A-15/18-F)

The power supply can be cut off by means of the main switch (12), thus enabling safe intervention during the equipment maintenance process. The equipment has protection against inversion of the power supply phases, and this monitoring is performed by the phase sequence relay (13). The system is controlled by a PLC (14) that, through signals received from the instruments installed in the equipment, performs the operation control command and system control through the turning on/off of the electric engines and electronic valves of the VLC unit. The adjustment of the working conditions as well as the monitoring of the parameters is done through an semi-graphic HMI (11).


The system has thermal relays (15) for protection, contactors (16), and modular relays (17) to drive the components via PLC. To power the instruments and the control system, the transformer (18) converts the supply voltage of the equipment to 220V, supplying the outlet (19) and the switched power supply (20), which in turn converts the voltage from the transformer to the control voltage (24 Vdc). The devices are protected by glass fuses (21). Interconnection between units is made through the switch (22). The available external connections are made through the terminal strip (23).



| Item | Description           |
|------|-----------------------|
| 13   | Phase sequence relay  |
| 14   | PLC                   |
| 15   | Thermal relay         |
| 16   | Contactor             |
| 17   | Modular relay         |
| 18   | Control transformer   |
| 19   | Power outlet          |
| 20   | Switched power supply |
| 21   | Fuse strip            |
| 22   | Switch                |
| 23   | Terminal strips       |

**1.1.3.2.** Electrical panel components - Version with inverter compressor (VLC-A-15/18-I)


In the case of the version with inverter compressor, there is also a general switch for disconnecting the equipment (12); however, due to the existence of the frequency inverter of the compressor (13), this VLC version does not require the use of the phase sequence relay and thermal relay, since the frequency inverter already has these protections. The other components follow the same pattern as the version with fixed compressor.



| Item | Description           |
|------|-----------------------|
| 13   | Frequency inverter    |
| 14   | PLC                   |
| 15   | Contactor             |
| 16   | Modular relay         |
| 17   | Control transformer   |
| 18   | Power outlet          |
| 19   | Switched power supply |
| 20   | Fuse strip            |
| 21   | Switch                |
| 22   | Terminal strips       |

### 1.2. Application scope

The VLC modular chiller can be applied in climatization systems of environments together with air handlers or in different sectors of the industry that require process cooling (extruders, injectors, blowers, welding equipment, laser cutting, and grinding machines, among others).


|   |                  |  |
|---|------------------|--|
|  | <b>ATTENTION</b> | Applications different from those intended for the product may put at risk the safety of the operator, the performance and even the breakage of a component of the VLC and the loss of warranty. |
|---|------------------|--|


1.3. Optional items installed at the factory or on the field

| Item                      | Installed in Factory | Installed on Field |
|---------------------------|----------------------|--------------------|
| Bacnet Communication      | ✓                    | ✓                  |
| Parallel interconnect kit | ⊗                    | ✓                  |
| Air filter                | ✓                    | ✓                  |
| Service HMI               | ✓                    | ✓                  |
| Condenser with e-coating  | ✓                    | ⊗                  |

2. Technical Features

2.1. Nomenclature







|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | <p>Check special documentation described in the annex of this manual for VLC that has special character (/C/T)</p> <p>Some data in this manual such as electrical data may not apply to the VLC that has special characters.</p> |
|---|--------------------|--|

## 2.2. Technical Information

| Basic Information         | Nominal Capacity         | -                     | 15TR                   |                        | 18TR                   |                        |
|---------------------------|--------------------------|-----------------------|------------------------|------------------------|------------------------|------------------------|
|                           | Model                    | -                     | VLC-A-15-I-220/380/440 | VLC-A-15-F-220/380/440 | VLC-A-18-I-220/380/440 | VLC-A-18-F-220/380/440 |
|                           | Compressor               | -                     | Inverter               | Fixed                  | Inverter               | Fixed                  |
| Nominal Capacity          | kW                       |                       | 52,7                   | 52,7                   | 61,5                   | 61,5                   |
|                           | TR                       |                       | 15                     |                        | 17,5                   |                        |
| Effective Capacity (1)    | kW                       |                       | 45,3                   | 50                     | 58,5                   | 65,4                   |
|                           | TR                       |                       | 12,9                   | 14,2                   | 16,6                   | 18,6                   |
| Minimum capacity (3)      | kW                       |                       | 13,5                   | 26,4                   | 18,2                   | 35,6                   |
|                           | TR                       |                       | 3,8                    | 7,5                    | 5,2                    | 10,1                   |
| COP Compressor (AHRI) (1) | kW/<br>kW                |                       | 3,353                  | 3,597                  | 3,193                  | 3,27                   |
| COP (AHRI) (1)            | kW/<br>kW                |                       | 2,993                  | 3,221                  | 2,933                  | 3,024                  |
| IPLV (1)                  | kW/<br>kW                |                       | 5,626                  | 5,069                  | 5,52                   | 4,802                  |
| Project Details           | Outlet water temperature | °C                    | 7                      |                        |                        |                        |
|                           | Return water temperature | °C                    | 12                     |                        |                        |                        |
|                           | ΔT Water                 | °C                    | 5                      |                        |                        |                        |
|                           | Water flow (1)           | m <sup>3</sup> /<br>h | 7,7                    | 8,5                    | 9,9                    | 11,1                   |
|                           | Load loss Perda de carga | kPa                   | 51                     | 57                     | 52                     | 61                     |
|                           | Evaporation temperature  | °C                    | 3,5                    | 3,3                    | 3,7                    | 3,5                    |
|                           | Environment temperature  | °C                    | 35                     | 35                     | 35                     | 35                     |
|                           | Condensation temperature | °C                    | 45,7                   | 46,6                   | 48,6                   | 50,3                   |
|                           | Overheating              | K                     | 6                      | 6                      | 6                      | 6                      |
|                           | Subcooling               | K                     | 6                      | 6                      | 6                      | 6                      |
|                           | Refrigerant fluid charge | kg                    | 4,6                    | 4,5                    | 5,8                    | 5,5                    |
|                           | Electrical voltages      | V                     | 220/380/440            |                        |                        |                        |
|                           | Total Maximum Power      | kW                    | 20,9                   | 22,6                   | 26,7                   | 29,7                   |
| Compressor Maximum Power  | kW                       | 19                    | 20,7                   | 24,8                   | 27,8                   |                        |
| Maximum Fan Power         | kW                       | 19                    | 1,9                    | 1,9                    | 1,9                    |                        |
| Total Maximum Current     | 220V                     | A                     | 59,1                   | 63,1                   | 75,83                  | 77,9                   |
|                           | 380V                     |                       | 33,2                   | 39,4                   | 41,84                  | 48                     |
|                           | 440V                     |                       | 32,6                   | 32,6                   | 41,24                  | 43                     |
| Starting current          | 220V                     | A                     | 88                     | 191                    | 155                    | 240                    |
|                           | 380V                     |                       | 44                     | 123                    | 44                     | 152                    |
|                           | 440V                     |                       | 44                     | 100                    | 44                     | 140                    |
| Operating Power           | kW                       | 15,134                | 15,524                 | 19,944                 | 21,624                 |                        |

|                        |                                       |            |      |                                    |          |                               |          |
|------------------------|---------------------------------------|------------|------|------------------------------------|----------|-------------------------------|----------|
|                        | Compressor Power                      |            | kW   | 13,5                               | 13,9     | 18,3                          | 20       |
|                        | Fan Power                             |            | kW   | 1,624                              | 1,624    | 1,624                         | 1,624    |
|                        | Operating Current                     | 220V       | A    | 43,32                              | 47,5     | 58,54                         | 61,5     |
| 380V                   |                                       | 23,17      |      | 28,6                               | 30,91    | 36,8                          |          |
| 440V                   |                                       | 21,51      |      | 23,7                               | 28,19    | 33,1                          |          |
| Dimensional            | Dimensions                            | Length     | mm   | 1000                               |          |                               |          |
|                        |                                       | Width      |      | 1175                               |          |                               |          |
|                        |                                       | Height     |      | 1615                               |          |                               |          |
|                        | Hydraulic Pipeline                    | Inlet      | pol  | 1.1/2                              | 1.1/2    | 1.1/2                         | 1.1/2    |
|                        |                                       | Outlet     |      | 1.1/2                              | 1.1/2    | 1.1/2                         | 1.1/2    |
|                        | Refrigeration Pipeline                | Discharge  | pol  | 3/4                                | 3/4      | 7/8                           | 7/8      |
|                        |                                       | Suction    |      | 1.1/8                              | 1.1/8    | 1.3/8                         | 1.3/8    |
|                        |                                       | Liquid     |      | 5/8                                | 5/8      | 3/4                           | 3/4      |
|                        | Components                            | Compressor | Type | -                                  | Inverter | Tandem (2x fixed compressors) | Inverter |
| Evaporator             |                                       | Type       | -    | BHPE (Brazed Plate Heat Exchanger) |          |                               |          |
| Condenser              |                                       | Type       | -    | MCHE (Microchannel) Curved         |          |                               |          |
| Fan                    |                                       | Type       | -    | Axial EC/BLDC                      |          |                               |          |
| Expansion valve        |                                       | Type       | -    | Electronic expansion valve         |          |                               |          |
| Refrigeration Pipeline |                                       | Suction    | pol  | 1.1/8                              | 1.1/8    | 1.3/8                         | 1.3/8    |
|                        | Discharge                             | pol        | 3/4  | 3/4                                | 7/8      | 7/8                           |          |
|                        | Liquid                                | pol        | 5/8  | 5/8                                | 3/4      | 3/4                           |          |
| Noise                  | Compressor sound power                | Partial    | dBA  | 74                                 | 80       | 77                            | 81       |
|                        |                                       | Total      | dBA  | 89                                 | 83       | 93                            | 84       |
|                        | Fan sound power                       | Partial    | dBA  | 82                                 |          |                               |          |
|                        |                                       | Total      | dBA  | 82                                 |          |                               |          |
|                        | Equipment sound power                 | Partial    | dBA  | 83                                 | 84       | 83                            | 85       |
|                        |                                       | Total      | dBA  | 90                                 | 86       | 93                            | 86       |
|                        | Equipment sound power (2 meters) (2)  | Partial    | dBA  | 66                                 | 67       | 66                            | 68       |
|                        |                                       | Total      | dBA  | 73                                 | 69       | 76                            | 69       |
|                        | Equipment sound power (5 meters) (2)  | Partial    | dBA  | 58                                 | 59       | 58                            | 60       |
|                        |                                       | Total      | dBA  | 65                                 | 61       | 68                            | 61       |
|                        | Equipment sound power (10 meters) (2) | Partial    | dBA  | 52                                 | 53       | 52                            | 54       |
|                        |                                       | Total      | dBA  | 59                                 | 55       | 62                            | 55       |

- (1) Operating conditions according to AHRI 551/591: Ambient temperature 35°C; Water inlet temperature 12°C; Water outlet temperature 7°C; Atmospheric pressure 101kPa.
- (2) (2) Noise level measured at a set distance from the equipment.
- (3) (3) Minimum operating capacity of the equipment in the following conditions: Ambient temperature 35°C; Water outlet temperature 7°C; Atmospheric pressure 101kPa.

|  |                    |   |
|--|--------------------|---|
|   | <b>ATTENTION</b>   | <p>The power in regime <b>SHOULD NOT</b> be used to size the electric protections and the power cable.</p> <p>To size the protections and power cable, use the maximum power described in the electrical data section.</p>  |
|   | <b>INFORMATION</b> | <p>Refrigerant Used: R-410A.</p>  |
|   | <b>INFORMATION</b> | <p>The power in regime is calculated based on the nominal operating condition of the equipment and it <b>SHOULD NEVER</b> be used to size the protections of the VLC, considering that the equipment may operate in conditions close to the maximum power of the equipment.</p>           |
|  | <b>DANGER</b>      | <p>The refrigerant R-410A has relative higher pressures than the R-22 normally used in the application of Chillers.</p> <p>No other refrigerant should be used in the cooling system of the VLC. The meters applied should be suitable to operate with pressures of the R-410A fluid.</p> |



### 2.3. Identification plate attached to the VLC

| Mecalor Soluções em Engenharia Térmica S/A<br>Rua da Bandeira, 219   São Paulo   CEP: 02181-170<br>CNPJ: 49.031.776/0001-68   CREA-SP: 0465739 |   |  |
|--|---|--|
| Modelo<br>Model / Modelo   | Fabricação<br>Manufacturing Date / Fabricación                      | Nº de série<br>Serial Number / Nº de Serie                       |
| <b>A</b> Alimentação elétrica<br>Power Supply / Alimentación Eléctrica   | <b>G</b> Potência instalada<br>Installed Power / Potencia Instalada | <b>L</b> Corrente nominal<br>Rated Current / Corriente Nominal   |
| <b>B</b> Capacidade nominal<br>Rated Capacity / Capacidad Nominal  | <b>H</b> Refrigerante<br>Coolant / Refrigerante                     | <b>M</b> Temp. de trabalho<br>Working Temp. / Temp. de Operación |
| <b>C</b> Condensação<br>Condensation / Condensación  | <b>I</b> Temperatura<br>Temperature / Temperatura                   | <b>N</b> Vazão requerida<br>Required Flow / Caudal Requerido     |
| <b>D</b> Bomba de processo<br>Process Pump / Bomba de Proceso  | <b>J</b> Peso (kg)<br>Weight / Peso                                 | <b>O</b> Aquecimento<br>Heating / Calentamiento                  |
| <b>E</b>   | <b>K</b>  | <b>P</b>   |
| <b>F</b> Observações e dados complementares<br>Remarks and Complementary Data / Observaciones y Datos Adicionales                              |   |  |
| SERVIÇO DE ATENDIMENTO AO CLIENTE<br>CUSTOMER SERVICE   SERVICIO DE ATENDIMIENTO AL CLIENTE<br>+55 (11) 2188-1700 atecnica@mecalor.com.br      |   | MADE IN<br><b>BRAZIL</b><br>www.mecalor.com.br                   |

**A** Abbreviation of the model

**B** Voltage (V), phases and frequency (Hz)

**C** Cooling heat capacity (kW)

**D** Type of condensation: air or water

**E** Flow rate (m³/h) of the process pump

**F** Special characteristics

**G** Month and year of manufacture

**H** Maximum electrical demand at full load (kVA)

**I** Cooling fluid

**J** Maximum room temperature

**K** Weight (kg)

**L** Tracking number

**M** Maximum current consumed (A)

**N** Working temperature of the process fluid

**O** Air flow required by the fan

**P** Heating capacity, when applicable


### 2.4. Operating limits

Some operating limits are described below and must be observed for good performance and operation of the equipment:





- Maximum outdoor temperature of up to 45°C;
- External ambient temperature of at least 5°C;
- Operation with water outlet temperature between 5 and 15°C.

## 2.5. Dimensions

### 2.5.1. VLC-15







### 2.5.2. VLC-18



## 2.6. Electrical Data

The customer is responsible for laying the electric cable up to the equipment and it must be performed by a qualified person.

Check the electrical features of the VLC on the identification plate attached to the equipment. The network voltage must comply with the VLC voltage and must be within the acceptable limits of  $\pm 10\%$  (Voltage variations with a tolerance of  $\pm 10\%$ : 220 V (198 ~242V); 380V (342 ~412V); 440 V (396 ~484V). The electrical data of the equipment will be presented below.

|   |                    |   |
|---|--------------------|---|
|    | <b>INFORMATION</b> | A power supply point is not necessary for the command/control circuit, because it is powered by the internal transformer of the equipment.  |
|    | <b>ATTENTION</b>   | Consult the standards applicable to the electrical installation at the site so as to ensure that the installation of the VLC is according to the specified standards and prerequisites.<br>For installations in Brazil, see standard NBR 5410 "Low Voltage Electrical Installations". |
|  | <b>ATTENTION</b>   | DO NOT USE the electrical data of the following table to size the power supply point in VLC models that have special characters (/B/C/E/T).<br>Check the special documentation described in the annex of this manual for VLC with special character.                                  |
|  | <b>ATTENTION</b>   | The maximum power informed on the electrical data table should be used to size the protections and cables.<br>DO NOT USE the power in regime that was calculated based on the nominal operating condition of the equipment.   |

| Equip. <sup>(1)</sup> | Voltage <sup>(2)</sup><br>(V) | Maximum<br>Current (A) | Cable <sup>(3)</sup><br>(mm <sup>2</sup> ) |
|-----------------------|-------------------------------|------------------------|--|
| VLC-A-15-I            | 220                           | 59.1                   | 25   |
|                       | 380                           | 32                     | 10   |
|                       | 440                           | 32                     | 10   |
| VLC-A-15-F            | 220                           | 63.1                   | 25   |
|                       | 380                           | 38.2                   | 10   |
|                       | 440                           | 32                     | 10   |
| VLC-A-18-I            | 220                           | 75.8                   | 35   |
|                       | 380                           | 40.7                   | 16   |
|                       | 440                           | 40.7                   | 16   |
| VLC-A-18-F            | 220                           | 77.9                   | 35   |
|                       | 380                           | 46.8                   | 16   |
|                       | 440                           | 42.4                   | 16   |

(1) Equipment in its configuration with fixed compressors or inverter compressor.

(2) Three-phase electrical voltage, at 60 Hz frequency, with an allowable variation of  $\pm 10\%$ .

(3) Diameter indication for cable per phase, for power supply of the main switch of the equipment. For distances greater than 50 meters, the cable should be resized.


### 3. Receiving


The receiving and moving of the equipment should be performed by the customer. In this stage, the following points should be checked:

- The data informed on the identification tag of the equipment should correspond to the information of the purchase order;
- The presence of all items, according to the order and invoice, and immediately inform the manufacturer in case of divergence or lack of items;

#### 3.1. Packaging

For transports carried out in the country, the shipping of the VLC is performed in a crate of wood wrapped in high resistance plastic. For export, the shipping is carried out in a closed fumigated wooden package. Both packages were designed to be transported exactly the way they are shipped.


|   |                  |  |
|---|------------------|--|
|  | <b>ATTENTION</b> | Do not pile boxes or deposit other volumes over package. |
|---|------------------|--|


|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | The VLC package was designed to ensure the integrity of the equipment during transport. |
|---|--------------------|---|


|  |  |  |
|--|--|--|
|  |  | Changes in the design of the package may result in damages on the equipment and loss of warranty |
|--|--|--|

**3.2. Unloading, Moving and Storage**

As soon as the unit is received and before unloading, check to see if the package of the VLC does not have any damages caused during transport.

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | It is recommended to move the VLC to the installation site or near the installation site with the original package |
|---|--------------------|--|


|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | It is recommended to store the VLC packaged in a dry place sheltered against dirt and bad weather in case the equipment remains unused for a long period of time before its installation and operation. |
|---|--------------------|---|


|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | Check the general condition of the equipment IMMEDIATELY after opening the package. In case any damage is observed, take a picture and send it to the shipping company. |
|---|--------------------|---|

Use a forklift or a pallet jack to unload. Check the weight of the equipment to define the capacity of the forklift that will be used to unload the equipment. Perform the transport with the equipment only in the vertical position. Transport the volume to the installation site or near it and unpack it.




In some cases, it is impossible to use the forklift, because the installation site is inaccessible, requiring the use of a munck truck or hoisting with a crane.




|   |                  |   |
|---|------------------|---|
|  | <b>ATTENTION</b> | Use canvas belts appropriate for the weight of the equipment to lift it. Unsafe practices may cause accidents, therefore, this process should be carried out by qualified people and with the suitable safety equipments. |
|---|------------------|---|

**4. Installation**

The VLC was designed thinking of efficiency, durability and safety of the operator; however, the safety should be ensured by the correct installation, preventive maintenance performed periodically and the operation within the design conditions.

|   |                  |  |
|---|------------------|--|
|  | <b>ATTENTION</b> | It is recommended for the installation of the equipment to be performed by Mecalor or by a qualified person. It is imperative for the installer to have a knowledge of local installation codes and regulations in order to ensure that the best mounting and safety practices are used. |
|---|------------------|--|


|   |               |  |
|---|---------------|--|
|  | <b>DANGER</b> | The VLC was not designed to work in an area classified as risk of explosion. If the use in these conditions is detected, the equipment will lose its warranty. |
|---|---------------|--|

**4.1. Installation site**


The good operation of the VLC depends mainly on the air flow that passes through the condenser; therefore, the equipment should be installed with good air circulation around it.

The floor where the VLC will be installed must be well leveled to avoid problems with water accumulation inside the equipment, as well as to maintain the correct return of the compressor oil and water from the hydraulic circuit. In case of the installation of various equipments in parallel, the bases must be leveled in the same plane.


Leave space around the unit to allow easy access for maintenance and provide good air circulation through the condenser. The VLC is designed for outdoor installation, so it is not necessary to install a cover over the equipment. If it is not possible to install it outdoors, it must be ensured that there is at least 2 meters of space between the fan and the environment cover, to avoid hot air recirculation in the place, impacting the refrigeration capacity of the equipment and possibly resulting in faults due to high-pressure refrigeration.





To facilitate access to the electrical panel and facilitate access for maintenance on the equipment, we recommend that there be 1 meter of space around the equipment.






|   |                           |   |
|---|---------------------------|---|
|  | <p><b>INFORMATION</b></p> | <p>Avoid installing the VLC in machining centers or in places with possible chips that may be deposited on the paint of the equipment. The chip deposited on the paint of the equipment may generate future problems of corrosion. In case it is not possible to install it in another location, clean the cabinet regularly to avoid the deposit of material on the structure.</p> |
|---|---------------------------|---|


|   |                           |   |
|---|---------------------------|---|
|  | <p><b>INFORMATION</b></p> | <p>The space required around the VLC also refers to low walls or any other obstacles that may compromise the circulation of air from the fan for the condenser.</p> |
|---|---------------------------|---|


|   |                           |   |
|---|---------------------------|---|
|  | <p><b>INFORMATION</b></p> | <p>During installation, it is recommended to protect the VLC to prevent dirt from surrounding works from settling in the equipment cabinet. It is recommended to carry out general cleaning after installing the equipment.</p> |
|---|---------------------------|---|

|   |                         |   |
|---|-------------------------|---|
|  | <p><b>ATTENTION</b></p> | <p>Never block the air inlet and outlet flow.</p> |
|---|-------------------------|---|

**4.1.1. Air exhaust duct**


When there is no suitable ventilation or when there is the possibility of air recirculation, a hot air exhaust duct should be installed.




|   |                           |  |
|---|---------------------------|--|
|  | <p><b>INFORMATION</b></p> | <p>The VLC is equipped with an axial fan, which is not designed to be ducted. The exhaust duct to be installed is a grille and must have the smallest length possible in order to not cause excess load loss and consequently deactivate the equipment due to high pressure.</p> |
|---|---------------------------|--|

The following recommendations should be considered in order to correctly size the air exhaust duct:


- Maximum load loss in the duct: 20 Pa
- The length of the duct should not exceed 2.5 m
- The duct should be placed between the roof/wall in order not to overload the structure of the VLC
- There should be a flexible canvas placed between the duct and the upper part of the fan in order to avoid the transmission of vibration to the roof/wall and enable maintenance of the fan
- The highest load loss of a duct is mostly on the very short radius curve ( $\ll D/2$ ). Curves of bigger radiuses or close to  $D/2$  avoid turbulent flow and excess load loss.


|   |                           |  |
|---|---------------------------|--|
|  | <p><b>INFORMATION</b></p> | <p>In case of doubts, consult Mecalor or the ASHRAE criteria for the correct size of the hot air exhaust duct.</p> |
|---|---------------------------|--|





|   |                           |  |
|---|---------------------------|--|
|  | <p><b>INFORMATION</b></p> | <p>Never restrict the air duct in the hot air outlet, this practice may cause the increase of load loss in the duct and deactivate the VLC due to high pressure.</p> |
|---|---------------------------|--|

#### 4.2. Electrical installation

The electrical installation from the main power point to the terminals of the main switch of the VLC is under the responsibility of the customer or the installer hired by him.

|   |                      |   |
|---|----------------------|---|
|  | <p><b>DANGER</b></p> | <p>Keep the main switch of the equipment always switched off at the time of installation or maintenance of the VLC. The noncompliance of this practice may cause personal damage or even death.</p> |
|---|----------------------|---|


|   |                         |   |
|---|-------------------------|---|
|  | <p><b>ATTENTION</b></p> | <p>Use blockades and warnings like <i>“Equipment Under Maintenance”</i> when the installation or intervention is occurring on the VLC. Consult standard NR12 and local references for the correct signal of the equipment in case of installation or maintenance.</p> |
|---|-------------------------|---|

|   |                  |   |
|---|------------------|---|
|  | <b>ATTENTION</b> | <p>DO NOT USE the power in regime to size the circuit breaker and power cable. The electric safety devices should always be sized according to the installed/maximum power of the VLC.</p>  |
|  | <b>ATTENTION</b> | <p>The customer is responsible for the sizing and selection of the exclusive disconnection device of the VLC. Unsuitable sizing or out of the local regulations may put at risk the safety of the installation, causes damages to the equipment and loss of warranty.</p>                         |
|  | <b>ATTENTION</b> | <p>Consult the standards applicable to the electrical installation at the site so as to ensure that the installation of the VLC is according to the specified standards and prerequisites.<br/>For installations in Brazil, see standard NBR 5410 “Low Voltage Electrical Installations”.</p>     |
|  | <b>DANGER</b>    | <p>High voltage in the connection boxes of the electrical panel, compressor, fan, reheating electric resistor and steam generator. Risk of injury or death. Only qualified personal with suitable safety equipment can handle these components and with the prior authorization from Mecalor.</p> |

Use an exclusive disconnection device (breaker) for the equipment and disconnect the three phases. The breaker and the power cable must comply with the electrical power requirements of the equipment, voltage and power described in the electrical data table in section 2.6 of this manual and support the current informed in it.


The electric power cables should enter through the back of the equipment and be laid up to the electrical panel through the indicated cable glands.

The R, S and T phases should be connected in the main switch and the ground cable in the green and yellow terminal.



#### 4.2.1. Interconnection between units

The VLC makes it possible to combine up to 14 units in the same system operating in parallel, thus increasing the refrigeration capacity of the system. In this application, one of the units (reference machine) is supplied with a switch for interconnection and communication between all units of the system. Besides the switch, the reference machine is equipped with a semi-graphic HMI, which allows the monitoring and configuration of all units. The other units (conventional machines) are supplied without an HMI on the door of the electrical panel, only with a button for activation and a lamp to signal alarms, as shown in the illustration below:



The switch for interconnection can be supplied in a version with the capacity to integrate up to 7 units or up to 14 units. CAT5e cable or higher should be used for the interconnection. We recommend that the cable does not exceed 100 meters of distance to the switch.


The VLC was developed so that the operation of the system does not depend on the reference machine; therefore, in case of a fault in the reference machine, the conventional machines will maintain the operation of the system, provided that the interconnection switch installed in the panel of the reference machine is kept energized.

#### 4.2.2. External connections

The VLC also has some contacts for interaction with external interfaces, such as the integration of a button for remote activation of the equipment, a fault signal contact (fault summary), as well as points for reading and controlling water pressure and flow. The connection should be made as follows:


##### 4.2.2.1. Remote start

Dry contact available for remote activation of the equipment.




#### 4.2.2.2. Enable flow


Contact intended for the activation control of an ON/OFF valve. This requires voltage to be available for activating the valve in question.




#### 4.2.2.3. Fault summary




#### 4.2.2.4. Pressure transmitter




#### 4.2.2.5. Flow transmitter



#### 4.2.2.6. Pressure control




#### 4.2.2.7. Flow control




**4.2.2.8. Remote audible alarm**

24Vdc voltage contact for connection of an external audible alarm.




**4.2.2.9. Serial communication**




**4.2.2.10. Ethernet**

For interconnection between equipment and network, and between equipment, CAT5e cable or higher must be used. The connection should be made through a switch for which the customer is responsible.

Parallel configuration must be used for terminal connection (the terminals must be crimped in an identical way in both terminals) and connection standard T568A or T568B can be followed, as shown in the figure below:



|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | <p>The wiring and piping described in the figure are only an example of a general electrical installation and it does not consider the installation variables of the customer. The electrical piping should comply with the applicable codes.</p> |
|---|--------------------|---|



**INFORMATION**

The pipe for laying the power cable shown in the figure is only an indication of the connection points and it is not planned for a specific installation.

#### 4.3. Hydraulic Installation

The hydraulic installation of the VLC must be according to the engineering practices and in agreement with the local regulations applicable to the standards of the industry.

Mecalor does not impose strict criteria for the selection of the materials that should be used in the design of the hydraulic pipe, but it recommends the minimum necessary for the correct installation of the VLC.

##### 4.3.1. Material

The material used in the hydraulic pipe may be in increasing order of cost, PVC, carbon steel, galvanized steel, copper and stainless steel. The installation with copper pipes and welded Yorkshire fittings presents the best cost-effective. Galvanized steel pipes have reasonable protection against corrosion and must be mounted with thread. An installation with PVC pipes connected with glue is the most economic solution, but it has the disadvantage of having low mechanical strength, and the tendency to break and crack with time. In counterpart, it is resistant to corrosion and the installation (as well as repair) is very simple.

**INFORMATION**

The internal pipe of the hydraulic circuit of the VLC and it is fully manufactured in stainless steel. Mecalor recommends the use of stainless steel for the design of the hydraulic pipe of the CP.

**INFORMATION**

Installing heat insulation on the entire length of the pipe prevents power consumption due to heat exchange of the pipe with the environment.

##### 4.3.2. Interconnection Points

The VLC has two interconnection points, one for the cooling water return point and the other for the cooling water outlet from the system. The VLC is supplied with 1.1/2" diameter Victaulic coupling type connections. After the coupling, a stainless steel AISI 304 pipe tip is also supplied, allowing the welding of this tip on the process piping or the direct connection on the Victaulic coupling.






We recommend that block valves be installed at the entrance and exit of the equipment, with the objective of facilitating eventual maintenance on the equipment, as well as preventing the circulation of water inside the heat exchanger at times when the equipment is inoperative and another unit installed in the same circuit is in operation (parallel installation). For applications with more than one unit the VLC can be supplied with a valve and pipe kit for parallel connection of the equipment. The components that make up the optional hydraulic interconnection kit are discussed in more detail in section 4.4.2 of this manual.

In addition to the block valves, we recommend the installation of a by-pass in the line to ensure a constant flow of water circulating through the VLC heat exchanger. Low water flow rates can result in water freezing inside the heat exchanger, causing severe damage to the plates of this component, resulting in water entering the refrigeration circuit, causing irreversible damage to the compressor, and loss of warranty.

|  |                    |   |
|--|--------------------|---|
|  | <b>INFORMATION</b> | We recommend the installation of the shut-off valves in the cold water return and outlet of the VLC for future maintenance. |
|--|--------------------|---|

|  |                  |  |
|--|------------------|--|
|  | <b>ATTENTION</b> | Do not use the cold water pipe of the VLC to support tool boxes or parts. The pipe was not designed to support objects, this practice may result in the rupture of the pipe and the stresses may be transmitted to the VLC, which may cause damages to its components. |
|--|------------------|--|


|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | Do not use valves that “strangle” the pipe. This practice may deactivate the equipment due to lack of water.   |
|  | <b>ATTENTION</b>   | It is expressly forbidden to restrict the VLC pipe in the cold water return and outlet. This practice may cause undue load loss in the system and even the lack of water at the consumption point.<br>The return and outlet pipe of the VLC was designed thinking on minimum load loss of the system, speed and flow suitable for the smallest tube diameter possible. |
|  | <b>DANGER</b>      | Never climb on the VLC pipe to carry out works at heights. The pipe was not designed to suffer specific overloads. This practice may result in the rupture of the pipe and consequent personal damages or even death.  |

#### 4.3.3. Interconnection in parallel

In applications with more than one VLC installed in parallel, there is the possibility of installing a single pump for the overall supply of the hydraulic circuit or installing individual pumps for each VLC installed.


##### 4.3.3.1. Interconnection with a single pump

In the installation with a single pump feeding the system, it is necessary to install an ON/OFF valve for each VLC. With this, only the valve of the operating VLC will remain open, immediately closing as soon as there is a rotation among the VLCs, or in case of the occurrence of any fault that interrupts the functioning of the operating VLC. Optionally, block valves can be installed at the entrance and exit of each equipment, with the purpose of facilitating eventual maintenance. The system must have flow balancing valves in each equipment, in addition to a by-pass in the line, thus ensuring constant pressure and flow of water in the system.



#### 4.3.3.1.1. Interconnection with single pump - Variable speed pump


In the single pump configuration, there is still the possibility of controlling the rotation speed of the pump, thus enabling more precise control of the water flow and pressure of the system. The system configuration should follow the same recommendations of the system with fixed rotation single pump, with the only requirement being to implement the flow meter that will be interconnected to the pump controller.



#### 4.3.3.2. Interconnection with individual pumps

In this installation format, each VLC is interlocked with its respective pump, where the pump is automatically shut off when the VLC ceases operation. This installation facilitates the balancing of the water flow between the modules, eliminating the need for balancing valves. We recommend the installation of a check valve in the return line of each VLC, to avoid the return of water through this line in inoperative equipment.


### Individual Pumps (On/Off)




#### 4.3.4. Need to add anti-freezing agent

In installations where the ambient temperature can reach values below 2°C it is recommended to add antifreeze in the process water, in order to avoid freezing the water, thus damaging the plates of the VLC plate heat exchanger (evaporator). We recommend the use of a solution of water and antifreeze according to the table below:

| Room temperature (°C) | Monoethylene-glycol |
|-----------------------|---------------------|
|                       | Volume (%)          |
| -5                    | 20                  |
| -8                    | 30                  |

|   |                    |   |
|---|--------------------|---|
|  | <b>INFORMATION</b> | In case another anti-freeze is used, care must be taken so that the freezing temperature of this solution is at least 5°C lower than the minimum working temperature. |
|---|--------------------|---|

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | To specify the quantity of the antifreeze, remember to consider the volume of the hydraulic pipes and the process. |
|---|--------------------|--|

#### 4.3.5. Pipe Cleaning


After completing the hydraulic interconnection services between the VLC and the process, make sure the cleaning of the pipe is performed before start-up of the equipment. This service should be performed to prevent fouling of small particles in the main components of the VLC.

Both fouling with the existence of suspended solids reduces the flow capacity of the water and increases load loss in the pipe, able to cause an increase in power consumption. Also, fouling may cause corrosion in the major components depending on the crusted material.

Cleaning should be performed after filling and purging the system, putting the equipment into operation and circulating water for a certain period of time. After this procedure, stop the circulation of water and clean the water filter. Reassemble the filter and carry out the circulation of water in the system again (repeat this procedure until the water filter is clean).

After observing that the filter is clean, drain all the water from the system and fill it again, after which the system is ready for operation.

We recommend the daily cleaning of the water filter during the beginning of operations, gradually spacing the cleaning time to that recommended in the preventive maintenance.

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | The equipment should not be switched on without prior authorization from Mecalor, under the penalty of suspension of the warranty. |
|---|--------------------|--|

#### 4.4. Optional Installation

##### 4.4.1. Bacnet Communication

The standard equipment has a Carel PLC and standard communication via MODBUS TCP/IP or MODBUS RTU RS-485, allowing the monitoring of parameters, remote on/off and setpoint adjustment. Optionally the system can be supplied with a plugin for Bacnet communication, if necessary for compatibility with management or monitoring software of the plant where the equipment is installed.

##### 4.4.2. Parallel interconnect kit


The VLC allows the interconnection of up to 7 units installed in parallel. To facilitate this interconnection, the system can be supplied with an interconnection kit for the units, containing the inlet/outlet interconnection pipes, collector pipes for the outlet and water return to the process, Victaulic connections, manual block valves, solenoid block valve, flow balancing valve, and a by-pass for the hydraulic circuit controlled by proportional valve. The manual block valves are installed in the inlet and outlet

connections of the VLC, with the purpose of allowing the isolation or removal of the equipment from the hydraulic line without impacting the operation of the rest of the system. The solenoid valve is installed in the outlet line of the VLC, and is controlled by the equipment's PLC, so that it is activated only when the equipment starts operating and immediately closing after the shutdown of the equipment, either by rotation routine between units or by the occurrence of a fault. The flow balancing valve is installed in the water inlet line of the equipment and its purpose is to keep the water flow constant in the system, thus ensuring a more stable temperature control in the process to be cooled. The electrical interconnection of the electronic valves contained in the kit is supplied ready to use.

#### **4.4.3. Air filter**

For the correct functioning of the VLC it is necessary to ensure that the condensation system of the equipment works without interferences, whether by low air flow, hot air recirculation, or dirt accumulation in the microchannel condenser.

Optionally, the VLC can be supplied with filters on the sides and rear of the equipment, protecting the microchannel condenser from dirt coming from the place where the equipment is installed. The filters are of the shaded screen type, being attached to the equipment by means of screws, thus enabling the removal of the filters for washing with a high-pressure washer, as will be addressed in section 6.2 of this manual.



#### **4.4.4. Condenser with e-coating**

For installations in environments subject to sea air or aggressive atmospheres, the conventional condenser may suffer corrosion due to its total aluminum composition, thus reducing its durability. To avoid this type of occurrence, it is possible to supply the VLC with a condenser with e-coating paint, which is a surface treatment in aluminum that provides protection against corrosion.

#### **4.4.5. Service HMI**

In an application with two or more VLCs installed in parallel, only the reference machine is supplied with HMI, being possible to monitor and control all the units through this HMI, according to information in section 4.2.1 of this manual. However, there is the option of providing an additional HMI for remote use in conventional units, in specific situations where it is necessary to view information from the HMI without the possibility of traveling to the reference machine, such as corrective maintenance, for instance.

The service HMI is already supplied with cable for connection to the PLC of the VLC.

#### 4.4.6. Remote Monitoring

As an option, the VLC can be supplied with the NEO remote monitoring system, which is independent of the local network for operation and allows remote assessments / interventions on equipment operating in national or international territory.

The NEO system allows monitoring via browser of the VLC's operating data, process variables and faults recorded 24 hours a day, bringing better reliability and safety to the process.

#### 4.5. Start-up check-list

### Final Inspection Checklist of the Installation Before Start-Up

| Installation site  | Hydraulic Installation   |
|--|--|
| <input type="checkbox"/> Is the general state of the VLC in perfect conditions to start operation?                     | <input type="checkbox"/> Was the interconnection between the VLC and the process carried out?                      |
| <input type="checkbox"/> Is the installation base of the VLC leveled?  | <input type="checkbox"/> Is the pipe diameter according to the water inlet and outlet diameter of the VLC?         |
| <input type="checkbox"/> Does the base of the VLC have channels or drain to drain out accumulated water?               | <input type="checkbox"/> Was the water filter installed?   |
| <input type="checkbox"/> Is the space required around the VLC as specified in the manual?                              | <input type="checkbox"/> Were shut-off valves were installed in the inlet and outlet of the VLC?                   |
| <input type="checkbox"/> Was the air exhaust duct sized correctly, without restrictions in the outlet? (if applicable) | <input type="checkbox"/> Was the interconnection carried out without diameter restriction along its entire length? |
| <b>Electrical installation</b>   | <input type="checkbox"/> Was an air trap installed at the highest point of the piping?                             |
| <input type="checkbox"/> Is the voltage and frequency the same as indicated on the plate of the VLC?                   | <input type="checkbox"/> Were the water quality criteria met?  |



Was the exclusive circuit breaker sized correctly according to the maximum power and voltage of the VLC?

Are there suitable supports attached to the entire length of the hydraulic pipe?

Was the power cable correctly sized according to the maximum power and voltage of the VLC?

Was the pipe duly insulated?


Was the power cable laid up to the terminals of the electrical panel?


Was the pipe cleaned?

Are the R, S and T phases connected correctly?

Was the water filter cleaned?

Was the VLC grounded?

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | After completion of the electric and hydraulic installation, fill the inspection checklist of the installation and request from the Technical Support department for execution of the start-up of the equipment with a minimum of 48 hours in advance. |
|---|--------------------|--|

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | The equipment should not be switched on without prior authorization from Mecalor, under the penalty of suspension of the warranty. |
|---|--------------------|--|

## 5. Operation

Below is a set of instructions for the correct operation of the VLC, as well as the change of the control temperature of the equipment and access to the alarm screens.

The operating actions do not require the use of PPEs unless the installation environment of the VLC demands it. The customer is responsible for establishing which PPEs the operator must use.


The customer must provide suitable lighting for the environment where the VLC is installed and where maintenance services will be performed, if necessary.

Before starting operation with equipment, we must:


- Check the electrical connections between the components, cables and terminals, tightening when necessary;

- Check the gauges and fittings of the electrical conductors;
- Check the gauges and fittings of the pipes;
- Check to see if the safety devices of the equipment and installation are not activated;
- Check the control fuses;
- Check the voltage and difference between the electric power supply phases;
- Check to see if the air flow of the unit is not blocked and if there is suitable ventilation in the equipment installation site.

The control of the equipment is done through the PLC installed in the electrical panel of the VLC, including all the functions related to temperature control.


|   |                         |   |
|---|-------------------------|---|
|  | <p><b>ATTENTION</b></p> | <p>It is recommended for the operator to go through training before operating the equipment.<br/>The VLC is easy to operate, but the operator must be qualified and have the minimum knowledge to operate the equipment safely.</p> |
|---|-------------------------|---|

### 5.1. Start-up

|   |                           |   |
|---|---------------------------|---|
|  | <p><b>INFORMATION</b></p> | <p>The equipment should not be switched on without prior authorization from Mecalor, under the penalty of suspension of the warranty.</p> |
|---|---------------------------|---|

All the equipment operation is done through the HMI installed on the front part of the equipment. The HMI (2), activation switch (3), and alarm indication led (4) are protected by an acrylic frame.


To start the operation of the equipment, after checking all items indicated in the previous section and activating the main switch (1), turn the activation switch (3) to the "ON" position. If the HMI (3) does not start operating, check if there is voltage at the inlet of the general switch of the equipment.



| Item | Description          |
|------|----------------------|
| 1    | Key Switch           |
| 2    | HMI                  |
| 3    | Drive switch         |
| 4    | Fault indication LED |

## 5.2. HMI – Human Machine Interface

Through the HMI of the main equipment, it is possible to perform all the configuration and control of the VLC, besides visualizing in real time the information referring to the operation status and process variables. Below is an illustration of the HMI interface in its initial screen:




| Item | Description      |
|------|------------------|
| 1    | Equipment status |

|    |                             |
|----|-----------------------------|
| 2  | Water Outlet Temperature    |
| 3  | Water temperature set-point |
| 4  | Water inlet temperature     |
| 5  | Cooling capacity            |
| 6  | Set-point adjustment        |
| 7  | Active alarms               |
| 8  | Programming                 |
| 9  | Return to previous screen   |
| 10 | Up directional button       |
| 11 | Enter                       |
| 12 | Down directional button     |

In the initial screen, we have the indication of the equipment status (1), and the equipment only starts operating when the switch button is pressed to the ON position. Next, we have the indication of the outlet water temperature for the process (2), water temperature set-point (3), process water return temperature (4), VLC refrigeration capacity (5), and a menu to adjust the set-point (6), which is activated by the enter button (11) while the HMI is in the initial screen. A password will be required to change the setpoint. The setpoint can be changed using the user password. By default, the passwords initially supplied are:

- Username: 10

In case of fault, the active faults can be viewed by pressing the active alarms button (7). The programming button (8) is used to access the main menu of the equipment. The main menu provides access to view all of the operating statuses and settings of the controller. After accessing the menu, use the return button (9) to go back to the initial HMI screen.




Inside the main menu will be the diagnosis menu, where it is possible to see all the VLC operation statuses. It is also possible to access the settings menu on it, where all the controller parameterization is done.

The VLC is supplied fully configured, with no need to change these settings for the initial operation of the equipment. The controller's factory password must be used to access the settings menu.

## 6. Maintenance

Carrying out the maintenance procedures at the recommended intervals will ensure the proper functioning of the equipment within the conditions for which it was designed and manufactured.


The maintenance activity must only be carried out by technical specialists who must observe and respect the rules and control the maintenance performed.

|   |                      |  |
|---|----------------------|--|
|  | <p><b>DANGER</b></p> | <p>Never perform any type of maintenance while the equipment is energized. This practice can put at risk the operator and the operation of the equipment, able to cause loss of control of the process, breakage of the equipment and physical damages to the operator, in addition to loss of warranty.</p> |
|---|----------------------|--|

### 6.1. Corrective Maintenance

All VLC faults are indicated on the HMI alarm screen. The failures of the VLC are divided into two types: Warnings and Alarms. In case a failure occurs on the VLC, before applying the procedures described below, check the failure log as described in the previous session.

When the fault is of the Alert type, it will only be registered in the fault history, however, in alarm condition, the icon indicating alarm is signaled on the HMI and the red led on the VLC panel is activated.

|   |                         |   |
|---|-------------------------|---|
|  | <p><b>ATTENTION</b></p> | <p>The procedures described below can only be performed by qualified people who have the knowledge on the operation of the equipment. Procedures performed by the layman may result in injuries or breakage of a component.</p> |
|---|-------------------------|---|

### 6.2. Fault indication

All equipment faults are recorded in the HMI fault history, however, the alarm signal is only issued when there are active alerts/alarms. Some alarms stop the operation of the equipment partially or completely and depending on the situation require an immediate diagnosis and solution.

When an alarm is identified, it is recommended to check the fault history to identify previously registered alerts, complementing the information for an accurate diagnosis.

| Description of the fault | Component |             | Consequence | Type  |       | Rearm  |           | Probable cause | Procedure |
|--------------------------|-----------|-------------|-------------|-------|-------|--------|-----------|----------------|-----------|
|                          | TAG       | Description |             | Alert | Alarm | Manual | Automatic |                |           |
|                          |           |             |             |       |       |        |           |                |           |

|                     |          |                          |                              |  |   |   |   |  |   |
|---------------------|----------|--------------------------|------------------------------|--|---|---|---|--|---|
| Control turned off  |          | Activation contact       | Does not enable any engine   |  | X |   | X | Open activation contact                | Check to see if the electrical contact is closed. If so, check for the presence of a 24V signal at the ID1 input connection wires. If there is no signal continuity, check for poor contact in the connection.  |
| Fan fault           | VT1      | Fan fault relay          | Turns off the cooling system |  | X | X | X | Disarm the fan thermistor              | Check to see if the voltage and current of the fan are within the specification of the electrical data table of the equipment. In case of abnormalities in the operating current, check for the existence of poor contact in the electrical connection, imbalance or lock in the fan or excess ambient temperature at the installation site of the equipment.   |
| Compressor thermal  | RT1, RT2 | Compressor thermal relay | Turns off the cooling system |  | X | X | X | Compressor thermal relay trip          | Check to see if the voltage and current of the compressor are within the specification of the electrical data table of the equipment. .   |
| High blood pressure | PHL1     | High-pressure switch     | Turns off the cooling system |  | X | X | X | High pressure in refrigeration circuit | Check the cleaning conditions of the condenser and the existence of hot air recirculation in the installation room of the equipment.  |
| Pressure fault      | PLL1     | Low pressure switch      | Turns off the cooling system |  | X | X | X | Low pressure in cooling circuit        | Carry out an alarm reset attempt. If the refrigeration system starts operating again, check if there are bubbles in the liquid display. In case the liquid display is bubbling, call a refrigeration technician to perform an analysis on the equipment in order to identify leakage points of the refrigerant fluid. If it is impossible to reset the fault, do not make any further attempts and call a refrigeration technician. |

|  |      |                                |                              |   |   |   |   |   |   |
|--|------|--------------------------------|------------------------------|---|---|---|---|---|---|
| Insufficient water                                     | FLL1 | Flow sensor                    | Turns off the cooling system |   | X | X | X | Low water flow  | Check for restrictions in the hydraulic circuit or malfunction in the process pump. If the water flow is found to be suitable, check for dirt on the flow sensor rod. |
| Fault inverter   | INV1 | Frequency inverter             | Turns off the cooling system |   | X | X | X | Alarm in the frequency inverter   | Check the active fault in the frequency inverter.   |
| Phase missing or sequence                              | RST  | Phase sequence relay           | Turns off the cooling system |   | X | X | X | Inversion or lack of power in one of the power supply phases of the equipment | Check if the RST phases are in the correct sequence and properly balanced.  |
| Water inlet sensor                                     | PTS1 | Water inlet temperature sensor | Turns off the cooling system |   | X | X | X | Temperature not within sensor reading range                                   | Check to see if the sensor is properly in the equipment.  |
| High/low temperature at the water inlet of the chiller |      |                                | Alert                        | X |   | X | X | Temperature not within setpoint   | Check for the existence of other alerts/alarms that are preventing the operation of the equipment.  |
|  |      |                                |                              |   |   |   |   | Bad contact in the sensor connection or open sensor                           | Check to see if the electrical connection of the sensor is according to the electrical diagram.   |

|   |      |                                      |                              |   |   |   |   |   |  |
|---|------|--------------------------------------|------------------------------|---|---|---|---|---|--|
| Water outlet sensor                                 | PTS3 | Water outlet temperature sensor      | Turns off the cooling system |   | X | X | X | Temperature not within sensor reading range         | Check to see if the sensor is properly in the equipment.   |
| High temperature at the water outlet of the chiller |      |                                      | Alert                        | X |   | X | X | Temperature not within setpoint                     | Check for the existence of other alerts/alarms that are preventing the operation of the equipment. |
| Low temperature at the water outlet of the chiller  |      |                                      | Turns off the cooling system |   | X | X | X | Low water temperature                               | Low thermal charge in the system or sensor reading error.  |
| Low temperature protection sensor                   | PTS2 | Evaporator outlet temperature sensor | Turns off the cooling system |   | X | X | X | Temperature not within sensor reading range         | Check to see if the sensor is properly in the equipment.   |
| Low temperature at the evaporator outlet            |      |                                      | Alert                        | X |   | X | X | Low water temperature                               | Low thermal charge in the system or sensor reading error.  |
|   |      |                                      |                              |   |   |   |   | Bad contact in the sensor connection or open sensor | Check to see if the electrical connection of the sensor is according to the electrical diagram.    |

|  |     |                                       |  |   |   |   |   |   |  |   |
|--|-----|---------------------------------------|--|---|---|---|---|---|--|---|
| Temperature below freezing temperature |     |                                       | Turns off the cooling system                                   |   | X | X | X |   |  |   |
| Water pressure sensor                  | TP1 | Water pressure transmitter (external) | Forces the bypass control output to the value set in parameter |   | X | X | X | Bad contact in transmitter connection or open transmitter | Check to see if the electrical connection of the transmitter is according to the electrical diagram. |   |
| High pressure in the hydraulic line    |     |                                       | Turns off the cooling system                                   |   |   |   |   | High pressure in hydraulic circuit                        | Check for obstructions in the hydraulic circuit.   |   |
| Liquid line sensor                     | TS3 | Liquid line temperature sensor        | Alert  | X |   | X | X | Temperature not within sensor reading range               | Check to see if the sensor is properly in the equipment.   |   |
|  |     |                                       |  |   |   |   |   |   | Bad contact in the sensor connection or open sensor  | Check to see if the electrical connection of the sensor is according to the electrical diagram. |
| High temperature in the liquid line    |     |                                       | Alert  | X |   |   | X | X   | Temperature above the value set in parameter   | Check if the parameter is adjusted according to the setup                                       |
|  |     |                                       |  |   |   |   |   | Sensor badly positioned                                   | Check to see if the sensor is properly in the equipment.   |   |

|   |     |  |                              |   |       |   |   |   |  |  |  |
|---|-----|--|------------------------------|---|-------|---|---|---|--|--|--|
| Low temperature in the liquid line        | TS3 | Liquid line temperature sensor               | Alert                        | X |       | X | X | Temperature below the value set in parameter              | Check if the parameter is adjusted according to the setup  |  |  |
|   |     |  |                              |   |       |   |   | Badly positioned sensor                                   | Check to see if the sensor is properly in the equipment.   |  |  |
| Suction temperature sensor                | TS4 | Suction temperature sensor of the compressor | Turns off the cooling system |   | X     | X | X | Temperature not within sensor reading range               | Check to see if the sensor is properly in the equipment.   |  |  |
|   |     |  |                              |   |       |   |   | Bad contact in the sensor connection or open sensor       | Check to see if the electrical connection of the sensor is according to the electrical diagram.      |  |  |
| Low pressure transmitter                  | PS2 | Low pressure transmitter                     | Turns off the cooling system |   | X     | X | X | Pressure not within transmitter reading range             | Check to see if the transmitter is properly positioned in the equipment.                             |  |  |
|   |     |  |                              |   |       |   |   | Bad contact in transmitter connection or open transmitter | Check to see if the electrical connection of the transmitter is according to the electrical diagram. |  |  |
| Low evaporating temperature               |     |  |                              |   | Alert | X |   | X   | X  | Temperature below the value set in parameter | Check if the parameter is adjusted according to the setup                |
|   |     |  |                              |   |       |   |   |   |  | Badly positioned transmitter                 | Check to see if the transmitter is properly positioned in the equipment. |
| Evaporating temperature at critical limit |     |  | Turns off the cooling system |   | X     | X | X | Temperature below the value set in parameter              | Check if the parameter is adjusted according to the setup  |  |  |



|                               |     |  |                              |                              |   |   |   |   |  |  |
|-------------------------------|-----|--|------------------------------|------------------------------|---|---|---|---|--|--|
|                               |     |  |                              |                              |   |   |   | Badly positioned transmitter                              | Check to see if the transmitter is properly positioned in the equipment.                             |  |
| High pressure transmitter     | PS1 | High pressure transmitter                      | Turns off the cooling system |                              | X | X | X | Pressure not within transmitter reading range             | Check to see if the transmitter is properly positioned in the equipment.                             |  |
|                               |     |  |                              |                              |   |   |   | Bad contact in transmitter connection or open transmitter | Check to see if the electrical connection of the transmitter is according to the electrical diagram. |  |
| High condensation temperature |     |  | Alert                        | X                            |   |   | X | X   | Temperature above the value set in parameter   | Check if the parameter is adjusted according to the setup                |
|                               |     |  |                              |                              |   |   |   |   | Badly positioned transmitter   | Check to see if the transmitter is properly positioned in the equipment. |
| Low condensation temperature  |     |  | Alert                        | X                            |   |   | X | X   | Temperature below the value set in parameter   | Check if the parameter is adjusted according to the setup                |
|                               |     |  |                              |                              |   |   |   |   | Badly positioned transmitter   | Check to see if the transmitter is properly positioned in the equipment. |
| Water flow transmitter        | TV1 | Flow transmitter (external)                    | Turns off the cooling system |                              | X | X | X | Pressure not within transmitter reading range             | Check to see if the transmitter is properly positioned in the equipment.                             |  |
|                               |     |  |                              |                              |   |   |   | Bad contact in transmitter connection or open transmitter | Check to see if the electrical connection of the transmitter is according to the electrical diagram. |  |
| Low water flow                |     |  | Alert                        | X                            |   |   | X | X   | Flow below the value set in parameter  | Check if the parameter is adjusted according to the setup                |
|                               |     |  |                              |                              |   |   |   |   | Badly positioned transmitter   | Check to see if the transmitter is properly positioned in the equipment. |
| Water flow at critical limit  |     |  |                              | Turns off the cooling system |   | X | X | X   | Flow below the value set in parameter  | Check if the parameter is adjusted according to the setup                |
|                               |     |  |                              |                              |   |   |   |   | Badly positioned transmitter   | Check to see if the transmitter is properly positioned in the equipment. |
| Discharge temperature sensor  | TS2 | Discharge temperature sensor of the compressor | Alert                        | X                            |   | X | X | Temperature not within sensor reading range               | Check to see if the sensor is properly in the equipment.   |  |
|                               |     |  |                              |                              |   |   |   | Bad contact in the sensor connection or open sensor       | Check to see if the electrical connection of the sensor is according to the electrical diagram.      |  |
| High discharge temperature    |     |  |                              |                              |   |   |   | Temperature above the value set in parameter              | Check if the parameter is  |  |

|   |     |                            |                              |   |   |   |   |   |   |
|---|-----|----------------------------|------------------------------|---|---|---|---|---|---|
|   |     |                            |                              |   |   |   |   |   | adjusted according to the setup   |
|   |     |                            |                              |   |   |   |   | Badly positioned sensor                             | Check to see if the sensor is properly in the equipment.  |
| Discharge temperature at critical limit |     |                            | Turns off the cooling system |   | X | X | X | Temperature above the value set in parameter        | Check if the parameter is adjusted according to the setup                                       |
|   |     |                            |                              |   |   |   |   | Badly positioned sensor                             | Check to see if the sensor is properly in the equipment.  |
| Ambient temperature sensor              | TS1 | Ambient temperature sensor | Alert                        | X |   | X | X | Temperature not within sensor reading range         | Check to see if the sensor is properly in the equipment.  |
|   |     |                            |                              |   |   |   |   | Bad contact in the sensor connection or open sensor | Check to see if the electrical connection of the sensor is according to the electrical diagram. |
| Low ambient temperature                 |     |                            |                              |   |   |   |   | Temperature below the value set in parameter        | Check if the parameter is adjusted according to the setup                                       |
|   |     |                            |                              |   |   |   |   | Badly positioned sensor                             | Check to see if the sensor is properly in the equipment.  |

|                          |      |                            |                              |   |   |   |   |  |   |
|--------------------------|------|----------------------------|------------------------------|---|---|---|---|--|---|
| High ambient temperature | TS1  | Ambient temperature sensor | Alert                        | X |   | X | X | Temperature above the value set in parameter       | Check if the parameter is adjusted according to the setup   |
|                          |      |                            |                              |   |   |   |   | Badly positioned sensor                            | Check to see if the sensor is properly in the equipment.  |
| Low SH                   | VEE1 | Electronic expansion valve | Turns off the cooling system |   | X | X | X | Low superheating                                   | Call a refrigeration technician to check the operation of the cooling system.   |
|                          |      |                            |                              |   |   |   |   | Reading error in the pressure sensors/transmitters | Check to see if the temperature sensors and pressure transmitters are making the correct reading. In case of abnormalities, check to see if the connection of the component is according to the electrical diagram. |
| High SH                  | VEE1 | Electronic expansion valve | Turns off the cooling system |   | X | X | X | High overheating                                   | Call a refrigeration technician to check the operation of the cooling system.   |
|                          |      |                            |                              |   |   |   |   | Reading error in the pressure sensors/transmitters | Check to see if the temperature sensors and pressure transmitters are making the correct reading. In case of abnormalities, check to see if the connection of the component is according to the electrical diagram. |

|     |      |                            |                              |  |   |   |   |  |   |
|-----|------|----------------------------|------------------------------|--|---|---|---|--|---|
| LOP | VEE1 | Electronic expansion valve | Turns off the cooling system |  | X | X | X | Low pressure                                       | Call a refrigeration technician to check the operation of the cooling system.   |
|     |      |                            |                              |  |   |   |   | Reading error in the pressure sensors/transmitters | Check to see if the temperature sensors and pressure transmitters are making the correct reading. In case of abnormalities, check to see if the connection of the component is according to the electrical diagram. |

|   |      |   |                              |   |   |   |   |  |   |
|---|------|---|------------------------------|---|---|---|---|--|---|
| MOP   | VEE1 | Electronic expansion valve                                      | Turns off the cooling system |   | X | X | X | High pressure  | Check the cleaning conditions of the condenser and the existence of hot air recirculation in the installation room of the equipment.  |
|   |      |   |                              |   |   |   |   | Reading error in the pressure sensors/transmitters     | Check to see if the temperature sensors and pressure transmitters are making the correct reading. In case of abnormalities, check to see if the connection of the component is according to the electrical diagram. |
| Prot - Damaged water inlet sensor   | PTS1 | Water inlet temperature sensor                                  | Alert                        | X |   | X | X | Bad contact in the sensor connection or open sensor    | Check to see if the electrical connection of the sensor is according to the electrical diagram.   |
| Prot - Damaged water outlet sensor  | PTS3 | Water outlet temperature sensor                                 | Alert                        | X |   | X | X | Bad contact in the sensor connection or open sensor    | Check to see if the electrical connection of the sensor is according to the electrical diagram.   |
| Prot - Damaged evaporator water outlet sensor                             | PTS2 | Evaporator outlet temperature sensor                            | Alert                        | X |   | X | X | Bad contact in the sensor connection or open sensor    | Check to see if the electrical connection of the sensor is according to the electrical diagram.   |
| High/low evaporating temperature outside the Zone 1...10 of the envelope  | C1   | Compressor (Only available in version with inverter compressor) | Alert                        | X |   | X | X | Compressor operating outside ideal envelope conditions | Call a refrigeration technician to check the operation of the cooling system.   |
| High/low condensation temperature outside the Zone 1...10 of the envelope |      |   |                              |   |   |   |   |  |   |
| Envelope outside of Zone 1...4  |      |   |                              |   |   |   |   |  |   |

|                                       |               |   |                              |   |   |   |   |  |   |
|---------------------------------------|---------------|---|------------------------------|---|---|---|---|--|---|
| Envelope outside Critical Zone 5...10 |               |   | Turns off the cooling system |   | X | X | X | Compressor operating outside the critical zone envelope  |   |
| High delta T                          | PTS1 and PTS3 | Inlet and outlet water temperature sensor | Alert                        | X |   | X | X | Difference between inlet (PTS1) and outlet (PTS3) temperature is greater than specified in parameter | Check if the parameter is adjusted according to the setup<br>Check whether sensors PTS1 and PTS2 are correctly positioned in the equipment and performing a correct temperature reading |
| Critical high delta T                 |               |   | Turns off the cooling system |   | X | X | X | Difference between inlet (PTS1) and outlet (PTS3) temperature is greater than specified in parameter | Check if the parameter is adjusted according to the setup<br>Check whether sensors PTS1 and PTS2 are correctly positioned in the equipment and performing a correct temperature reading |

### 6.3. Preventive Maintenance

The correct Preventive Maintenance of the equipment may avoid future breakdowns and shutdowns of the equipment. For this, we recommend the procedures described below.

| Preventive Maintenance – General  |                  |  |   |
|-----------------------------------|------------------|--|---|
| Item                              | Frequency        | Procedure  | Notes   |
| Painting Structure                | Monthly          | Check the general condition of the cabinet painting and retouch if necessary   | Cabinet color specifications: olive green color: RAL 6003   |
| Insulation of the pipe            | Every six months | Check the insulation conditions of the pipes and replace damaged insulations   | Damaged insulations or insulations with excess moisture should be replaced.                                 |
| Vibration                         | Every six months | Check for excess vibration in the equipment.<br>Place your hand on the body of the compressor and visually check the pipe; this procedure is necessary to obtain a reference standard in relation to the normal vibration of the equipment | Check for possible cracks on welded points.   |
| Fixation of components            | Every six months | Check the engine fittings: fan and compressor  | Retighten loose bolts.  |
| Air filter (side closing screens) | Monthly          | Clean the side closing screens   | It is recommended to increase the cleaning frequency in environments with high rate of suspended particles. |

|  |         |  |  |
|--|---------|--|--|
|  |         | Check the condition of the closing screen                                      | Replace if damaged.  |
| Water filter                               | Monthly | Remove the filter element, wash and reinstall                                  | It should not be mounted with missing discs.   |
| Equipment door                             | Monthly | Open and close the door  | The door should be aligned and closed without difficulty.  |
| Equipment door locks                       | Monthly | Close the door, lock it and then unlock it                                     | There should be no interference between the latch and the door. The door should be pressed against the rubber seal and not allow gaps. |
| Alignment and closing of the set of plates | Monthly | Check the alignment of the closing plates of the cabinet                       | They should be aligned and must not have any fixation bolts.   |
| Insulation of the electrical panel         | Monthly | Check the fastening of the seal and possible damages to the seal of the panel. | Carry out the replacement of the electrical panel seal.  |
| Water leak                                 | Monthly | Check the hydraulic piping/connections for water leakage (or signs of leakage) | Retighten the connections.   |
| Process water condition                    | Monthly | Check the appearance of the process water                                      | It must be translucent and without solid particles.  |
|  |         |  | If not, take a sample and send it for analysis (see annex on Water Quality).   |

| Preventive Maintenance - Mechanical |                  |  |  |
|-------------------------------------|------------------|--|--|
| Item                                | Frequency        | Procedure  | Notes  |
| Fan                                 | Monthly          | Check for excess vibration in the fan  | Retighten the bolts  |
|                                     |                  | Check cleaning of the fan  | Clean the fan  |
| Evaporator                          | Every six months | Check to see if it is necessary to clean the evaporator fins.  | Clean the blades of the condensers with compressed air at low pressure (be careful not to bend the exchanger fins)                   |
|                                     |                  | Check for signs of encrustation on the fins of the heat exchanger  | In case of signs of encrustation, call for technical support to assess and eventually carry out technical cleaning of the exchanger. |
| Compressor                          | Monthly          | Check the oil level in compressors with oil display  | With the compressor switched off, the oil level should at least be 1/4 and at most 3/4 of the display                                |
| Condenser                           | Monthly          | Clean the fins of the condenser with the use of a WAP (be careful not to dent the fins of the condenser) | It is recommended to increase the cleaning frequency in environments with high rate of suspended particles.                          |
|                                     |                  | Check the room air temperature   | The ambient temperature must not exceed 45°C   |
| Refrigeration piping                | Monthly          | After 2 minutes of operation, check to see if the liquid display indicates the dark color and no bubbles | If the display indicates a light color, there is moisture in the system. If it shows bubbles, there is refrigerant leak              |


|  |  |   |   |
|--|--|---|---|
|  |  | Check for signs of oil leak in the pipe | The fluid leak should be corrected as soon as possible. Complete the refrigerant gas and oil load of the compressor, if necessary |
|--|--|---|---|

| Preventive Maintenance – Electrical |                  |   |   |
|-------------------------------------|------------------|---|---|
| Item                                | Frequency        | Procedure   | Notes   |
| Electrical Panel                    | Every six months | Check for any loose components of the electrical panel  | Retighten the terminals or bolts  |
|                                     |                  | Measure the fan currents and compare them to the current specified in the equipment checklist | Motor operation should be checked when currents are above specified                   |
| Engine switch box                   | Every six months | Check to see if the junction box terminals of the engines are coming loose                    | Retighten the terminals or bolts  |
| Temperature sensors                 | Monthly          | Check the calibration of the temperature sensors  | Compare the outlet and return air temperatures with a calibrated standard thermometer |
| Clean the electrical panel          | Every six months | Clean inside the electrical panel   | The electrical panel should be clean, without dust and fillings                       |
| Terminal strips                     | Every six months | Check to see if all the electric cables are connected to their respective terminals           | There should be no loose wires or "jumpers" inside the electrical panel               |
| Fan                                 | Monthly          | Measure the current of phases R, S and T  | Compare the currents indicated in the electrical data of the equipment                |
|                                     |                  | Check the voltage variation between phases  | It should not exceed 10%.   |
| Compressor                          | Monthly          | Measure the current of phases R, S and T  | Compare the currents indicated in the electrical data of the equipment                |
|                                     |                  | Check the voltage variation between phases  | It should not exceed 10%.   |

### 6.2.1. Cleaning procedure of the water filter, air filter and microchannel condenser


#### 6.2.1.1. Water filter


The water filter of the VLC consists of four main components, as described in the image below:




Carry out the following steps in order to clean the filter:

- i. Switch off the VLC and close the stop valves;
- ii. Remove the cover of the filter in order to have access to the filter element;
- iii. Slacken the bolt that keeps the discs attached to the body of the element;
- iv. Wash the discs with running water preferably with a high pressure washer;
- v. Retighten the bolt, mount and reposition again the filter element on the filter body ensuring that no disc is missing.

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | Leave a small gap between the discs when retightening the bolt of the filter element. Excess torque applied the torque will leave the filter element rigid and will compromise the filtration process. |
|---|--------------------|--|

|   |                  |  |
|---|------------------|--|
|  | <b>ATTENTION</b> | Never put the VLC into operation without water filter. This practice will leave the evaporator vulnerable to clogging, which can cause the water inside the evaporator to freeze, resulting in the rupture of the plates, causing severe damage to the equipment and loss of warranty. |
|---|------------------|--|


|   |                  |   |
|---|------------------|---|
|  | <b>ATTENTION</b> | The use of the filter without the filter element or with a reduced number of discs compromises the efficiency of the equipment filtration and may result in the suspension of the warranty. |
|---|------------------|---|

#### 6.2.1.2. Air filter (Optional Item)

The optional air filters consist of a screen mounted on an aluminum frame and have the function of retaining solid particles coming from the installation environment (dust, insects, leaves, debris), preserving the microchannel condenser of the equipment. The periodic wash of the air filter is essential for the good performance of the equipment.


We recommend using a high-pressure washer for cleaning the filters.

The washing of the air filter should be carried out every 30 days, but in case the installation site is very dirty, it is recommended to increase the cleaning frequency.



#### 6.2.1.3. Cleaning of the inverter filter

For VLC models equipped with the inverter compressor, there is a frame inside the cabinet for protection of the frequency inverter. To ensure proper operation and preserve the integrity of the inverter, it is necessary to ensure that there is good ventilation for the inverter. The inverter panel has air filters to prevent dirt from entering the panel and the inverter itself. We recommend that the filter elements of the air filters be cleaned monthly, or more often depending on where the VLC is installed.




#### 6.2.1.4. Microchannel condenser



It is extremely important for the cleaning of the microchannel condenser to be carried out periodically. This process, in addition to extending the life of the condenser, prevents equipment breakdowns from occurring due to obstructions caused by dirt, filings and dust.

The following precautions should be taken when cleaning the condenser:

- i. Remove the air filters from the sides of the equipment structure (if the VLC has been supplied with this option);
- ii. Use a high pressure washer with spray nozzle to wash the condensers with clean water;
- iii. The jet of water from the spray nozzle should be in the form of a fan and directed perpendicular to the surface of the condenser to prevent the fins from being dented.
- iv. The jet of water cannot be applied on a direct point of the surface of the condenser;
- v. Keep a distance of 300mm between the spray nozzle and the surface of the condenser.



## 7. Technical Services

In addition to quality products, Mecalor offers its customers personalized services through a specialized team, aligned with the technological innovations of the market and prepared to offer solutions suitable to the need of the customer.

### 7.1. Start-up

Despite being a very simple procedure, it is important for the customer to contact Mecalor in order for the installation conditions to be checked and for the start-up to be authorized.

### 7.2. Preventive Maintenance Agreements

With aim to prevent failures, Mecalor offers customized preventive maintenance agreements. The agreements consist of the periodic visits of technicians who check, gauge and test the condition and performance of the equipments.

The Mecalor Preventive Maintenance Plan ensures the correct operation of your equipment and reduces the possibility of shutdowns due to failure.

### **7.3. Retrofitting (Reform of Equipments)**

In many cases an equipment with outdated technology may be technologically updated through the application of modern techniques developed by Mecalor. Mecalor Retrofitting Service consists of:

- Study of the current conditions of the equipment, evaluating whether retrofitting is worthwhile;
- Study of the adaptability of the equipment to the new technology;
- Execution of the scope;
- Try-out;
- Project Documentation.

### **7.4. Training**

Mecalor conducts specific training to meet the most diverse preparation needs of the maintenance and operation teams. The trainings are provided according to necessity.

## **8. Disposal and the environment**

The VLC should be disposed at the end of its service life so as to reduce any negative impact on the environment. The following are recommended for such:

- Dismount the equipment according to all the safety recommendations applicable in the execution of the maintenance services;
- Reuse its components by applying it in other machines or in the production process, such as: reuse of the centrifugal pump, its electric motor, etc.;
- Separate materials that can be recycled and send them for recycling; for example: recycle carbon steel steel, bronze, plastics, etc.;
- Separate non-reusable materials and components and dispose of them, observing the effective legal recommendations. Special attention should be given to batteries, lubricant oil and refrigerant.

In case there is leakage of the compressor oil of the PS, on any surface, immediate containment should be provided, pouring sawdust over the oil and then, after absorption, collect the sawdust and carry out complete cleaning of the affected area. This waste should be stored in an exclusive container for proper disposal afterwards.

During the replacement of the lubricant oil in the VLC, the container and remaining excess oil should be stored in a suitable place to subsequently be sent to recycling.

In case refrigerant leakage is detected in the equipment, maintenance should be requested urgently.

Any mechanical or electric component that is replaced due to failure or upgrade should be disposed according to the recommendations and effective rules.

## 9. Warranty Term

### 1. OBJECT AND VALIDITY

- 1.1. The warranty includes repair and/or replacement of any faulty component, as long as it is due to fabrication defect..
- 1.2. The validity of the warranty of the equipments manufactured by Mecalor is 365 days counted from the date of issuance of the sales invoice of the product, of which there are 90 consecutive days of legal warranty and 275 consecutive days of complementary warranty, the latter provided by Mecalor as an additional benefit to the customer.
- 1.3. In case the equipment is purchased with extended warranty, this should be recorded in the official business proposal issued by Mecalor and it exclusively consists of the increase of the complementary warranty, being that the legal warranty will always be 90 consecutive days.
- 1.4. This warranty term is valid only for products sold and used in Brazil.

### 2. WARRANTY VALIDATION

- 2.1. The customer should inform Mecalor technical support in writing immediately after identification of the possible manufacturing defect.
- 2.2. Once the information of the possible defect is received, the technical support team of Mecalor should evaluate the possible causes and issue a technical opinion.
- 2.3. In case the manufacturing defect is confirmed, Mecalor must provide the replacement or repair of the defective component within the shortest period of time possible.
- 2.4. The Warranty period offered by Mecalor covers the costs for repair and replacement of parts with manufacturing defect, including expenses with the transport of technicians and tools, equipment freight or expenses with shipping of parts and components to the billing address of the equipment.
- 2.5. It is mandatory for the customer to return the defective components to Mecalor to confirm the failure at the supplier (if applicable), under the penalty of bearing the costs involved.
- 2.6. The warranty establishes the execution of services during business hours, with additional charge for extra hours of services provided outside this period and transport fee for services performed on the installations of third parties.

### 3. LOSS OF WARRANTY

- 3.1. The warranty will lose its validity in case it is confirmed through technical evaluation that the defect is as a result of failures during transport, installation, startup, maintenance or improper use by the customer or third parties.
- 3.2. Start-up of the equipment can only be performed by the customer with the written authorization form the technical support of Mecalor or with the presence of our authorized technicians, when this optional service is part of the Mecalor scope of supply, under the penalty of loss of warranty.
- 3.3. Incompatibility caused by products purchased from third parties and installed with Mecalor products or application in noncompliance with the information established in our technical and business proposal.
- 3.4. The warranty will lose its validity if the contracting party fails to comply with purchase and sales agreement, even if the agreement is tacit, including regarding the compliance of the equipment purchased.


### 4. GENERAL EXCLUSIONS AND LIMITATIONS

- 4.1. Once Mecalor provides technical support in warranty within the limits established by law and by the good service practices, we shall not be held responsible for direct or indirect costs or loss of revenue eventually supported by the customer as a result of eventual equipment defect.
- 4.2. The customer will be responsible for the expenses with eventual shipping of the equipment to the factory or to any authorized technical representative of Mecalor to carry out technical support.
- 4.3. The replacement of components due to use or natural wear of the equipment, such as seals, sensors, engines, contactors, circuit breakers, among others.
- 4.4. Normal operating adjustments, maintenance and application of the equipment, such as sending of technicians to check the safety alarms, parameterization and technical assistance to optimize the performance of the product.

| Customer | Serial number | Warranty period |
|----------|---------------|-----------------|
|          |               |                 |

## 10. Attachments

The documents that complement this manual are described below and may be different from standardized documents. In case the nomenclature of the MCA has a special character, consult the specific documentation applied to the equipment.

|   |                    |  |
|---|--------------------|--|
|  | <b>INFORMATION</b> | Consult the special documents in case the nomenclature of the MCA has a special character as described in the <i>nomenclature</i> section in the <i>technical characteristics</i> chapter of this manual.. |
|---|--------------------|--|

### Complementary documents of this manual:

- Dimensional;
- Wiring diagram;
- Flowchart;
- List of Components;
- Water quality;
- Setup;
- Electrical Data Table.